SAMSUNG

RADIO CASSETTE RECORDER
CD PLAYER
RCD-S30

SERVICE Manual

RADIO CASSETTE RECORDER CD PLAYER

CONTENTS

1. Alignment and Adjustments
2. Exploded Views and Parts List
3. Electrical Parts List
4. Block Diagrams
5. PCB Diagrams
6. Wiring Diagram
7. Schematic Diagrams

ELECTRONICS

© Samsung Electronics Co.,Ltd. FEB. 2003
Printed in Korea
Code no. AH68-01225H